

## Venetian blind measurement instructions

Measure the desired width of the venetian blind by the inside of the window recess or on the wall. Maintain a margin of 0,5 cm on both sides in order to avoid the lamella's of the venetian blind to run against the plastering or the wall. When the blind is to be installed within the window recess, it's always necessary to measure the upper, middle and the lower part of the window recess. When deciding whether you want your control on the left or the right side, you should take into account the direction the window or door opens/closes in, as well as other relevant qualities of the window or room in which the blind is to be installed. Attention: it's not possible to alter the control side afterwards.

## Installment

It's important to follow the installment instructions accurately. We decline any responsibility in the case the instructions are not, or wrongly carried out. Horizontal venetian blinds are quite fragile. In order to avoid bending and damaging of the blind we recommend you to handle it with care, and always with both hands.

The venetian blind will be delivered including supports for attachment of the blind to the wall or the ceiling.

1. Mark the position of the supports on the wall or the ceiling. The distance between the supports shouldn't be less than 100 cm. Fix the supports evenly along the entire width of the blind, and take into account the position of the mechanism in the upper box of the blind. Be aware of possible obstacles such as handles of doors or windows. Level all the supports and attach them in one line.
2. Having screwed down the supports tightly in their position, you open them up, and hang the box of the blind on the supports. First of all you put the front part into the support and then you press the back part into position. Subsequently you close the supports to fasten the blind.

All the offers and agreements we make are subject to our general conditions